

QUADRO 24 dmx channel's functions and their values :

Channel		Value	Control Programs
CH1	RGB luminance adjust	0~136	Adjust total luminance
	RGB color change	137~187	CH5=0、adjust color change speed
	RGB gradual color change	188~239	CH5=0、adjust gradual color change speed
	Run Inside-set effect	240~255	Automatic-running effect
CH2	Red	0~255	Adjust Red LED luminance
CH3	Green	0~255	Adjust Green LED luminance
CH4	Blue	0~255	Adjust Blue LED luminance
CH5	Flash	0~255	Adjust flash pace
	CH1 Set flash frequency	137~239	Adjust RGB flash color change frequency